

Supervisor Password

User Password

Installed

Not Installed

Administrator Password

User Password

Password Check

Setup

Chassis Intrusion

Clear Chassis Intrusion Event

Memory Different Alert

Reset Memory Size Warning

Flash Write Protection

BIOS Lock

Hard Disk Security

P1:SATA CVB-8D256

Password Check

Setup

Always

No

Disabled

Disabled

Description

Setup: Check password while invoking setup. Always: Check password while invoking setup as well as on each boot.